


BILLIE REMOTE QUICKSTART



SETTINGS

Settings are activated by double-clicking the **SETTINGS** key and the following keys:

- POWER:** starting volume
- VOLUME UP:** ⌘ (Bluetooth) pair
- SOURCE LEFT:** ⌘ previous song
- VOLUME DOWN:** tube lights off
- SOURCE RIGHT:** ⌘ next song
- MUTE:** mute pre/sub out

*Example: by double-clicking the **SETTINGS** key followed by the **POWER** key, the current volume is registered as the preferred starting volume.*

All settings but the starting volume reset to default once the power is turned to standby. Turning off the amp using the switch on the backpanel resets all settings to factory default.

*Please remove plastic battery tab before 1st time use.